



Pin 16 next to USB port



J2 + J3 headers for mounting BNO085
Feather will only have headers for pins 2,3,4 (P0, P1, BNO_RST), snip the rest after soldering



P0 = D9
P1 = D6
BNO_RST = D5







Title		
Size A	Number	Revision
Date: 12/03/2024		Sheet of
File: C:\Users\..\Sheet1.SchDoc		Drawn By: